



Shed Care Instructions & Warranty Information

Congratulations! We hope you enjoy your Cosy storage shed :). To get the most out your shed, there are a few things you need to do make sure your shed lasts as long as possible:

Safety Information

For safety please ensure that your storage shed is sited on solid, stable, flat, hard standing ground. We also recommend that you site it against a wall, building or fence and secure it in place to reduce any chance of severe weather tipping or damaging the shed.

To help avoid falls, ensure children do not climb on the shelves, clamber up the shed sides or swing on the doors. Ensure its use is always well supervised.

Warranty & Care instructions

Our 2 year shed warranty covers against general timber rot and decay - It does not cover against timber splits or warping as these can occur naturally over time.

Please note: Sheds can be prone to changes in appearance and shape, especially in extreme weather conditions. These will not affect the structural integrity of the product, this is a natural feature and not covered in the warranty.

To ensure that your product warranty is valid, it is critical that you follow these procedures:

- Site the product on hard, level ground with good drainage such as tarmac, concrete or paving.
- If you are fixing your shed to a wall or fence; please make sure that any holes made are treated, that there is a gap left at the back for water to drain off the roof and that you don't pierce the felted areas.
- Ensure that the shed is not positioned under or next to trees, bushes or foliage.
- Do not store wet items in the sheds without appropriate ventilation or moisture control.
- The treatment on the shed MUST be re-applied every year. You can do this by purchasing a good non-toxic stain and applying it liberally to the outer panels of your shed.
- If the blackboard paint begins to deteriorate, you can refresh this by sanding off the spoiled paint and reapplying over this area. You can purchase this paint directly from Cosy or any respectable hardware retailer.
- For any self assembly sheds, ensure that it is fully and correctly assembled. Any damage or issues caused by incorrect assembly are not covered against.
- Ensure that at the end of each session, the doors are completely closed with all latches used where applicable to help lessen any warping over time.

****NOTE:** Please be sure that any stains or paints used are child-friendly and non-toxic.

Your thoughts

If you have any great photos of how you use your shed, we would be delighted to see them! Please email these or any ideas you have to ideas@cosydirect.com and you may see them in our next catalogue!